



User Manual

Many thanks for your decision to buy a LignUhr wood watch. You are going to have much pleasure wearing it.

Even with the most accurate production methods there are a few elements that you should pay careful attention to.

Please carefully read the operating instructions so you will have a long pleasure wearing your beautiful masterpiece.

Guido Styger
Geschäftsführer LIGNUHR

Functions:

1. Normal position
2. Date correction
3. Setting the hands; seconds-stop interrupting the motor impulse

Blocking time for quick calendar correction: 21.30 hrs to 00.30 hrs



Warranty

A guarantee of two (2) years is given for this wood watch. No claim can be made as to the replacement of a broken (wood) part, but solely on the repair work.

There is an exclusion from guarantee for:
damage by improper handling,
lack of care or normal wear and tear through wearing and ageing processes (e.g. scratched glass; changes of the colour of wood).
Also excluded from the guarantee is the service life of the battery.

Important

The watch is protected against dust and humidity, it is however not water-resistant. Please avoid therefore contact with water and generally staining objects.

Long contact with fluids may result in stains as fluids may seep into the wood. Don't expose the watch to strong sunlight or to ultraviolet light. Please avoid direct contact with solvents and cleansing agents (fragrances, cosmetic products etc.)

Maintenance

Your LignUhr wood watch has been treated with high-quality oil that serves as a protection against dirt and humidity.

For cleaning the watch use dry fabrics or a damp cloth for very dirty spots (subsequently use dry fabrics).

If unused keep the watch in a light protected place.

LIGNUHR
c/o Styger Schreinerei GmbH
Hofstrasse 4
6416 Steinerberg
Switzerland
support@lignuhr.ch
www.lignuhr.ch